

Orbit LED Ceiling Light Installation Guide

We strongly recommend that you read this manual carefully before installation.
Installation **MUST** be carried out by a qualified and licensed electrician.



Replacement
Warranty

Models Parameters:

MLOO34512	Martec Orbit 290mm LED Oyster Light 12w Tricolour
MLOO34518	Martec Orbit 330mm LED Oyster Light 18w Tricolour
MLOO34524	Martec Orbit 380mm LED Oyster Light 24w Tricolour
MLOO34528	Martec Orbit 380mm LED Oyster Light 28w Tricolour

Installation Instructions

The diagram illustrates the internal components of the Orbit LED Ceiling Light, including the CCT Switch, Plate housing, LED Modular, Driver, Terminal block, and Rubber grommet. A separate view shows the Terminal block Connection with wires. A Diffuser Cover labeled 'A' is also shown.

Step 1. Disconnect power
Step 2. Remove diffuser 'A' by twisting anticlockwise
Step 3. Drill required holes in the ceiling using the holes in the fixture 'B' as a template
Step 4. Use screws and suitable fixture system to secure the fixture to the ceiling ensuring that the mains wire is through the entry hole 'C'
Step 5. Connect the Active (L), Neutral (N) and Earth according to the markings on the terminal block
Step 6. Select Colour Temperature by toggling the switch on driver
Step 7. Re-attach diffuser 'A'
Step 8. Restore power

WARNING

- Installation of product **MUST** follow SAA standards and meet local authority regulations
- Installation **MUST** be carried out by a qualified and licensed electrician
- Light **MUST** be earthed
- Light **MUST** be firmly installed to a flat solid surface, wall or ceiling
- **DO NOT** immerse any part of the light fitting into water or any form of liquid
- **DO NOT** look directly into the LED light
- The warranty is **VOID** if product is not installed according to this installation guide

2 Year Replacement Warranty

Visit our website for details <https://www.martec.com.au/warranty-statement/>

E: sales@martec.com.au

W: martec.com.au