

Vancouver LED Wall Light Installation Guide

We strongly recommend that you read this manual carefully before installation.
Installation MUST be carried out by a qualified and licensed electrician.




Replacement
Warranty

Models Parameters

MLXVE27WBM 60W IP44 Exterior Wall Light (E27 lampholder)


Installation Instructions

Step 1




Switch off the mains.

Step 2




Unscrew and remove the mounting bracket using the allen key supplied.

Step 3




Mount the bracket on the desired surface using the screws supplied.

Step 4




Wire to main as illustrated.

Step 5




Attach fitting back onto the bracket using the allen key supplied.

Step 6



Screw E27 lamp into the lamp holder.
(lamp not included)


Step 7



Switch on the mains.

Accessories Included

1x allen key
2x washers
2x wall plugs
2x screws



Vancouver LED Wall Lights

Installation Guide

Data Table

Models	Power (W)	PF	CCT (K)	Weight (KG)	Operation Temperature (Degree)	IP
MLXVE27WBM	60	≥0.5	N/A	0.75	+40° -20°	44

WARNING

- Installation of product **MUST** follow SAA standards and meet local authority regulations.
- Installation **MUST** be carried out by a qualified and licensed electrician.
- Light **MUST** be earthed.
- Light **MUST** be firmly installed to a flat solid surface, wall or ceiling.
- **DO NOT** immerse any part of the light fitting into water or any form of liquid.
- **DO NOT** look directly into the LED light.
- The warranty is **VOID** if product is not installed according to this installation guide.

2 Year Replacement Warranty

Visit our website for details <https://www.martecaustralia.com.au/warranty-statement/>

